


## Changing current language to communicate between non-English computers with WMicrotracker

### In Windows 7:


In Windows 7, open the *Control Panel* and click the "*Clock, Language, and Region*" link.



In the "*Clock, Language, and Region*" panel, click on *Region and Language*.



This opens the *Region and Language* window. There, go to the *Administrative* tab. In the "*Language for non-Unicode programs*" section, you can see the currently set language. To change it, first click on *Change system locale*.



You should select "English (United States)"

Restart Computer after changes

#### **In Windows XP:**

1. Go to Control Panel (the desktop version)
2. Clock, Language, and Region.
3. Region.
4. Click on the Administrative tab on the top.
5. Under Language for non-Unicode programs, select the button Change system locale , then select "English" display language.
6. Restart your computer.